

# Suzuki Bandit Shorty GP Exhaust



## Table of Contents

Table of Contents.....	Page 1
Parts Required.....	Page 1
Tools Required.....	Page 1
Step 1, Remove Factory Exhaust System.....	Page 2,3
Step 2, Install Slip on.....	Page 3
Trouble Shooting.....	Page 3

## Parts

1 Slip-on

## Tools Needed

- Phillips Screwdriver
- 12mm Socket Wrench
- 12mm Wrench

**\*Disclaimer: This item may or may not be legal within your state or country. This exhaust is for off-road and show use only. We are not liable for any damages that may occur from the use of this product. Professional installation and tuning is recommended for best performance. If you do not agree to these terms, please return the item.**

**Note: It is normal for some fiberglass packing to come out of the exhaust during the initial start-up and break-in period. The break-in period is approximately 200 miles.**

**This exhaust comes fully assembled with a baffle and exhaust packing already installed. Figure 0.1 is the baffle that is inside the exhaust. The baffle is a straight through design to allow maximum exhaust flow with minimal restriction.**

Figure 0.1



## **Step 1**

### **Remove factory exhaust system**

#### **Tools Required**

- 12mm Socket Wrench
- Allen Wrench

#### **Parts**

- none

1. Unbolt the exhaust clamp. Figure 1.1

FIGURE 1.1



2. Unbolt the exhaust bolt that is mounted to the right passenger foot peg. Figure 2.2

FIGURE 2.2



3. Slide the factory exhaust off of the headers.

## Step 2

### Attaching your new Slip-on Pipe

#### **Tools Required**

-12mm socket

#### **Parts**

- Slip-on short pipe

1. Attach the exhaust into your headers.
2. You will be using your factory clamp to install this exhaust.
3. Tighten the bolt on the clamp with a wrench.

NOTE: If you have tightened your exhaust all the way and the exhaust is still loose, you will need to replace your exhaust donut gasket.

(NOTE: DO NOT REMOVE THE BAFFLE UNLESS YOU ARE REPACKING YOUR EXHAUST)

### **Trouble shooting**

- 1. If your exhaust touches your swing arm**
  - a. Your slip on may be mounted wrong, adjust your exhaust and tighten clamp.
  
- 2. If your exhaust is not sturdy**
  - a. Bolts or screws may be loose, tighten all bolts and screws.
  - b. You may need to use your factory exhaust donut gasket if your bike came with one.
  
- 3. If you have any other problems, contact: [support@radiantcycles.com](mailto:support@radiantcycles.com)**

**Loud and Alive.**  
**Radiant Cycles**

